


BG4/FOS

Operating Manual
Technical Description
Installation Instruction


BG4/FOS

Operating Manual Technical Description Installation Instruction




Version 1.0.0

Wiring Schematic




Connection to SCP500/800

A maximum of one BG4/FOS allowed on SCP500/800



Connection to third-party equipment



Mounting

The BG4/FOS can be fitted to a standard recessed back box, or surface mounted using the included surface back box.

Operation

Turn the key to the left to send an OPEN command to the SCP500/800 control unit.

Turn the key to the right to send a CLOSE command to the SCP500/800 control unit.

Version 1.0.0



Teal Products Ltd
Unit H, Alexandra Way
Ashchurch, Gloucestershire,
GL20 8NB, UK

01242 620318
sales@tealproducts.co.uk
www.tealproducts.co.uk