


BG6/FOS

Operating Manual
Technical Description
Installation Instruction

BG6/FOS

Operating Manual Technical Description Installation Instruction




Version 1.0.2

BG6/FOS


Operating Manual
Technical Description
Installation Instruction

Wiring Schematic



Connection to SCP500/800

A maximum of one BG6/FOS allowed on SCP500/800



Mounting

The BG6/FOS can be fitted to a standard recessed back box, or surface mounted using the included surface back box.

Operation

Turn the key to the left to send an OPEN command to the SCP500/800 control unit.

Turn the key to the right to send a CLOSE command to the SCP500/800 control unit.

Version 1.0.2



Teal Products Ltd
Unit 8A, Orchard Trading Estate,
Toddington, Cheltenham,
GL54 5EB, UK

01242 620318
sales@tealproducts.co.uk
www.tealproducts.co.uk